


Electronically Filed
 FIRST CIRCUIT
 1DTA-25-00071
 05-NOV-2025
 11:30 AM
 Dkt. 256 EXH

BUTTON ACTION RECAP



Action	Button Actions
Power On	Press Power button until short vibration. Camera starts and enters Ready (Buffering) mode.
Power Off	Press and hold Power button for 3 seconds.
Start recording	Double-press Event button.
End recording	Press and hold Event button for 3 seconds.
Add marker to recording	While recording, press Select button.
Increase speaker volume	Press Volume ▲ button.
Decrease speaker volume	Press Volume ▼ button.
Turn lights on or off	Press and hold Volume ▲ button for 3 seconds.
Enter Stealth mode	Press and hold Volume ▼ button for 3 seconds.
Exit Stealth mode	Press and hold Volume ▲ or Volume ▼ button for 3 seconds*.
Activate display backlight	Double-press Select button. Display backlight turns on for 5 seconds.
Pairing	Simultaneously press Event and Program buttons, then release.

* The camera remembers volume and light settings when exiting Stealth mode.



Case I.D. No. 1DTA-25-00071

Plaintiff's

Defendant's

State's

Exhibit


9

Date NOV - 5 2025

[Signature]

Clerk, District Court of the First Circuit

AB3 DISPLAY




Status Bar

Activity Area

Status Bar Icon	Description
	Battery capacity
	Camera paired
	Lights off
	Stealth mode on
	Battery low warning (to the right of the battery capacity icon)


Activity Area Icon	Description
	Ready (Buffering) mode
	Recording
	Recording started by Axon Signal broadcast*



AB3 DISPLAY & NOTIFICATIONS

Operating Mode or Action	Camera Display (Activity Area)	Operation LED	Audio Notification	Haptic Notification (Vibration)
Power on	READY	Solid red	Two short rising-pitch tones	One - long duration
Power off	STARTING	Solid red	Three short lowering-pitch tones	One - long duration
Recording started by Event button double press	STARTING	Blinking red	Two short tones	Two - short duration
Recording started by Axon Signal	STARTING	Blinking red	Two short tones	Two - short duration
Recording reminder	RECORDING	Blinking red	Two short tones every 2 minutes	Two - short duration every 2 minutes
Stop recording, return to Ready	SAVING <small>green</small> READY	Blinking green	One long tone	One - long duration
Volume up or down	VOLUME	Blinking green or red	One short tone at new volume level	One - short duration
Enter Stealth mode	STEALTH	Off	None	None
Exit Stealth mode	NO CHANGE	Blinking green or red	None	Two - short duration
Event marker captured	EVENT MARKER	Blinking red	None	One - short duration
Low battery notifications: 20% battery capacity and every 5% decrease OR any error	BATTERY LOW	Blinking yellow	Four quick high-pitch tones	Four - short duration
Camera enters Pairing mode	PAIRING	Blinking blue	Three short rising-pitch tones	None


MONUMENTS





APPROVED HPD MOUNTS




**Double
MOLLE**




Flexible



**OuterWear
Magnet**



**Wing
Clip**




**Small
Pocket**

PAIRING MODE




AXON

Enter Pairing Mode: Press
the Program AND Event Button
at the same time





AXON VIEW



PROVIDES THE FOLLOWING CAPABILITIES


- Pairs ABB with **DEPARTMENT ISSUED MOBILE PHONE ONLY**
- Instant replay
- Live video streaming assists with optimal camera placement
- Real-time metadata input enables accurate retention
- Adjust ABB settings





DEPARTMENT ISSUED MOBILE PHONE ONLY

-Click on the Axon View App on your mobile phone



Axon View
Axon Enterprise Inc. Video Players & Editors
Everyone
Add to Wishlist

2.2


Install

-If your department issued phone don't have the app, download the Axon View App on to your phone.


PAIRING YOUR AB3




Step 1




Step 2



Step 3



Step 4



SELECT BODY 3




TAP INITIATE PAIRING



ENTER AGENCY



Username/password




PAIRING YOUR AB3




Step 5a

1. Power on the AB3
2. Press the Program AND Event button at the same time to place the AB3 into Pairing mode
3. The Operation LED, if enabled, will blink blue and the LCD Display will display "PAIRING"




PAIRING YOUR AB3

Step 5b



3. The Operation LED, if enabled, will blink blue and the LCD Display will display "PAIRING"



PAIRING YOUR AB3



Step 6

CHOOSE CAMERA


SEARCH

SCANNING FOR CAMERAS

Please allow your device to scan for cameras.

X601950A8


Details



SCAN FOR CAMERAS



Step 7



MATCH AB3 SERIAL #
TO AXON VIEW



Step 8



CONNECT CAMERA


Connecting to your Axon Camera

CONNECT

PAIRING YOUR AB3

Step 9

When your AB3 is paired with your phone, you will see a chain-link icon on the Status Bar.



AB3 | LCD DISPLAY

 AXON